# Perlite Loose-Fill Perlite, an inorganic mineral, is as permanent as the walls it insulates. Masonry Insulation

The physical character of expanded perlite lends itself to a variety of special purposes – including use as loose-fill masonry insulation. For a detailed explanation of perlite expansion, see Infosheet: "Why Perlite Works"

#### **PROPERTIES & BENEFITS**

*Insulation:* Thermal performance tests have shown significant energy savings when perlite is used to fill the cavities in concrete masonry structures.

## Standards, Specifications and References:

Perlite is represented in the standards by ASTM product specification C549. The ASTM test methods used to evaluate loose-fill Perlite insulation are listed below.

- ASTM C549 "Specification for Perlite Loose-Fill Insulation"
- ASTM C520 "Test Methods for Density of Granular Loose Fill Insulations"
- ASTM C1363 "Test Method for Thermal Performance of Building Materials and Envelope Assemblies by Means of a Hot Box Apparatus"
- ASTM E 84 "Test Method for Surface Burning Characteristics of Building Materials"
- ASTM E 136 "Test Method for Behavior of Materials in a Vertical Tube Furnace at 750°C"

#### Non-Combustible: Perlite attributes—

- The temperature range for perlite fusion is 2,300-2,450°F (1,260-1343°C).
- Perlite is a Class A, Class 1 building material
- Flame spread 0; Smoke density 0
- 4 Hour Fire Ratings: Underwriters Laboratories
  Design No. U905 shows that a 2 hour rated 8, 10, or
  12 inch (20, 25, or 30 cm) concrete block wall is
  improved to four hours when cores are filled with
  perlite. UL Designs U901, U904, and U907 also
  achieve 4 hour fire ratings.



## R AND U-VALUES FOR CONCRETE BLOCK ASSEMBLIES WITH AND WITHOUT PERLITE

BLOCK SIZE	BLOCK TYPE	Perlite Fill	R-Va <b>l</b> ue	U-Va <b>l</b> ue	
6 in. (15cm)	Lightweight	No Yes	2.59 <b>5.24</b>	0.39 <b>0.19</b>	
8 in. (20cm)	Lightweight	No <b>Yes</b>	2.86 <b>6.95</b>	0.35 <b>0.14</b>	
10 in. (25cm)	Lightweight	No <b>Yes</b>	3.06 <b>8.46</b>	0.33 <b>0.12</b>	
12 in. (30cm)	Lightweight	No <b>Yes</b>	3.11 <b>9.90</b>	0.32 <b>0.10</b>	
6 in. (15cm)	Heavyweight	No <b>Yes</b>	1.80 <b>2.58</b>	0.56 <b>0.39</b>	
8 in. (20cm)	Heavyweight	No <b>Yes</b>	1.96 <b>3.26</b>	0.51 <b>0.31</b>	
10 in. (25cm)	Heavyweight	No <b>Yes</b>	2.08 <b>3.82</b>	0.48 <b>0.26</b>	
12 in. (30cm)	Heavyweight	No <b>Yes</b>	2.14 <b>4.32</b>	0.47 <b>0.23</b>	

- 1 R-values with units ft²-hr-°F/Btu were calculated using the Isothermal Planes Method described in the ASHRAE Handbook of Fundamentals.

  The U-value with units Btu/ft²-hr-°F is the reciprocal of the R-value.

  The R-values and U-values include interior and exterior air-film resistances that total R 0.85.
- 2 R-values are based on apparent thermal conductivity for loose-fill perlite of 0.32 Btu·in./ft²-hr·°F, thermal conductivity of 2.97 Btu·in./ft²-hr·°F for light-weight concrete and 8.93 Btu·in./ft²-hr·°F for normal-weight concrete.
- 3 Block Density: Lightweight block nominal 85 lbs/ft³ (1.36 kg/l); Heavyweight block nominal -135 lbs/ft³ (2.16 kg/l)
- 4 RSI = R/5.678

## Perlite Loose-Fill Masonry Insulation

**Permanent:** Perlite is an inorganic, naturally occurring mineral and is as permanent as the walls which contain it. It supports its own weight and will not settle or bridge.

*Economical:* Perlite loose-fill masonry insulation offers excellent thermal and fire resistant properties at an economical cost. It is lightweight and pours easily and quickly without requiring special equipment or skills.

TABLE 2

## THERMAL RESISTANCE VALUES for VENEER and CAVITY WALL CALCULATIONS

	R Values (°F•ft²•h/Btu)	R Values (K•m²/W)
Outside Air Film	0.17	0.03
Common Brick (w/ holes)	0.20	0.04
Face Brick (no holes)	0.44	0.08
Air Space in Cavity <sup>3</sup> /4 to 4 in (19-102 mm)	0.97	0.17
1 inch (2.5 mm) cavity filled w/ perlite	3.12	0.55
2 inch (5.1 mm) cavity filled w/ perlite	6.25	1.10
3 inch (7.7 mm) cavity filled w/ perlite	9.38	1.65
4 inch (10.3 mm) cavity filled w/ perlite	12.5	2.20
Reflective Air Space	3.08	0.54
Furring (nonreflective air space)	1.01	0.18
Gypsum or Plaster Board <sup>1</sup> /2 inch (13 mm)	0.45	0.08
Gypsum or Plaster Board <sup>5</sup> /8 inch (16 mm)	0.56	0.10
Inside Air Film	0.68	0.12





PERLITE INSTITUTE

## Perlite Loose-Fill Masonry Insulation INSTALLATION GUIDE

TABLE 3										
APPROXIMATE PERLITE MASONRY BLOCK LOOSE-FILL COVERAGE: BY AREA*  NUMBER OF 4 ft³ BAGS REQUIRED (4 ft³ EQUALS ~ 110 LITERS)										
	COR	CORE FILL: BLOCK SIZE			CAVITY FILL: CAVITY WIDTH					
WALL AREA ft² (m²)	6 INCH (15cm)	8 INCH (20c	m)	12 inch (30cm)	1 INCH (2.5cm)	2 INCH (5	5.0cm)	3 INCH (7.5cm)		
1,000 (93)	46	46 65		118	21	42		62		
APPROXIMATE PERLITE MASONRY BLOCK LOOSE-FILL COVERAGE: BY BLOCK COUNT*  COVERAGE PER 4ft³ BAG (4ft³ EQUALS ~ 110 LITERS)										
	12-INCH (30cm) BLOCK		10-	-INCH (25cm) BLOCK	8-INCH (20cm	8-INCH (20cm) BLOCK		6-INCH (15cm) BLOCK		
Number of Blocks Fille	ed 9	9		13	17			23		
	1 INCH (2.5cr	1 INCH (2.5cm) CAVITY		INCH (3.9cm) CAVITY	2 INCH (5.1cm) CAVITY		2.5 INCH (6.4cm) CAVITY			
Square Feet of Wall Fill	ed 48	48		32	24		19			
*Adjust coverage to compensate for filled/reinforced cavities.										

## **GUIDELINES FOR USE:**

## Materials

It is recommended that the loose-fill perlite shall conform to the requirements of ASTM Designation C549. Ask your supplier to provide documentation that the product conforms to ASTM C549 Standard Specification for Loose Fill Insulation.

#### Installation

- **1.** The loose-fill perlite should be installed in the following locations:
  - **a.** In the cores of all exterior (and interior) hollow masonry walls.
  - **b.** In the cavity between all exterior (and interior) masonry walls.
  - **c.** Between exterior masonry walls and interior furring.

- 2. The loose-fill perlite should be poured directly (or via a hopper) in the top of the wall at any convenient interval (not in excess of 20 ft [6 m]). Wall sections under doors and windows should be filled before sills are placed. Rodding or tamping is not recommended.
- **3.** All holes and openings in the wall through which loose-fill perlite can escape should be permanently sealed or caulked prior to installation. Screening should be used in all weep holes. (The inclusion of weep holes is considered good construction design practice to allow passage of any water which might penetrate the cavities or core spaces of wall construction.)
- **4.** The loose-fill perlite must remain dry. Suitable means should be used as the work progresses to insure that the insulation is protected from inclement weather.